User’s Guide: DSB-1168 / DSR-1168 / DSS-1168

Bluetooth

NEW

Bluetooth Speaker

Living Thing

Good Sound-quality Intelligent

About the Product

The newly product is the upgraded product based on the first generation, not only with much better sound quality,but add the humanized intelligent voice prompt,handfree and spare power function. New product must can bring completely new impression and enjoy.

Product Control Sketch Map

Speaker control sketch map



1. Pause/Play: click for pause/play;hold for

2. Adjust the volume. Click ◂◂ for volume down, Click ▸▸ for volume up.

3. Handfree button

4. Status indictor:slowly flash of Blue light for power on,quickly flash for Bluetooth pair; red for AUX play.

5. Microphone

6. Power switch: Orange for power off.

7. LINE IN external audio connect socket: Plug in for external audio mode,Pull out for Bluetooth play mode.Set up

The connection method for Mobile

1. Turn the power switch on the bottom of Speaker,the prompt tone "product has prepared well,waiting for pair"; Pls hold ▸II until the indicator on the top changed from flash slowly to fast.

2. Open the phone Bluetooth device(The methods differ from different cellphone brands), then enter into search status; when successfully paired,"product has been paired"prompt sound comes out, at the same time,"LIVIN THING"showed on the phone; now you can play the music.the time of search and pair differs from different cellphone brands,In generation, It takes about one minute.

Attention:Once paired successfully, both the speaker and your Bluetooth device will store the device. when you use another cellphone, please turn off it

and hold the to pair again.

3. Adjust the volume by press or hold ◂◂ /▸▸ on the top of speaker,press ▸II can play or pause.

4. Handfree.when there is a call,the speaker will announce the number automaticly,then just press this button to answer,the speaker will come back to music-play after the end of call.

5. Power off:When not in use, please turn off the switch to orange status to prevent the waste of power.

Method of Charging

1. Method of external charging: Pull the switch to "CH", Put the speaker on the spare Power,Connect the USB lable to the computer or 5V/1A Power,Red indicator flash for charging of speaker and blue for the spare Power.The indicator will extinguish when full power.

2. Method of spare battery: Pull the switch on the spare power to "PS",the green indicator flash,now you can charge through USB lable by connecting with cellphone or other mobile device,at the same time charge for the speaker.when not in use, pull the switch to "CH" to prevent the waste of power.

For the tablet computer's set-up method,please refer to the mobile's.

Set up for the laptop.

As there are so many bluetooth versions of laptop,the connect methods differ.the new version Driver should be installed in your computer when it can't be connected for your first use. Pls call the after-sales service call or ask for help to the technicians when there is any problem.

Trouble shooting

1.Can not pair successfully: (1)Check whether the speaker is in standby and searching mode.(2)Check whether there are too many Bluetooth receivers around your Bluetooth device. Turn off them to avoid any disturbance. And pair again.

2.The sound is small or distorted:Check the volume setting on both the speaker and your Bluetooth device and adjust the volume to a suitable level.

3.Can not play properly, the music is intermittently: Check whether the distance between the speaker and your Bluetooth device is out of its working distance, or whether there are some obstacles block the communication between the speaker and the Bluetooth device.

4.No charging showed when the speaker on the spare power: put the speaker on the spare power and confirm Ok then plug in the USB lable,please check the switch on"PS"or not when charge by the spare power.

5.Play/Pause doesn't work:please try the player of cellphone or others.

Specifications:

Output power:1.5W
Bluetooth V2.1+EDR(A2DP) function
Working distance: ġ10 M (Distance differs from different cellphone Bluetooth d evices and the environments)
Speaker power:3.7V 500mA
Spare power: 3.7V 1020mA
Output voltage:5V 500mA

Spare power sketch map:

1. Product charging point
2. Charging mode change-over switch"CH"for charging input mode. "PS"for charging for other cellphones.
3. Power on status i ndicator.
4. USB charging IN/OUT port.